














www.tulon.ru

SLP
*SCOPE LENS
PROTECTOR*
USER MANUAL

BA-614-25, 03/2017





	SLP-O	SLP-E
Z8i 1-8x24	SLP-O-24	SLP-E-46
Z8i 1,7-13,3x42 P	SLP-O-42	SLP-E-46
Z8i 2-16x50 P	SLP-O-50	SLP-E-46
Z8i 2,3-18x56 P	SLP-O-56	SLP-E-46
Z6(i) 1-6x24	SLP-O-24	SLP-E-46
Z6(i) 1-6x24 EE	SLP-O-24	SLP-E-46
Z6(i) 1,7-10x42	SLP-O-42	SLP-E-46
Z6(i) 2-12x50	SLP-O-50	SLP-E-46
Z6(i) 2,5-15x56 P	SLP-O-56	SLP-E-46
Z6(i) 2,5-15x44 P	SLP-O-44	SLP-E-46
Z6(i) 3-18x50 P	SLP-O-50	SLP-E-46
Z6(i) 5-30x50 P	SLP-O-50	SLP-E-46
Z5 3,5-18x44 P	SLP-O-44	-
Z4i 1,25-4x24	SLP-O-24	-
Z4i 3-12x50	SLP-O-50	-
Z4i 2,5-10x56	SLP-O-56	-
Z3 3-10x42	SLP-O-42	-
Z3 4-12x50	SLP-O-50	-
X5(i) 3,5-18x50 P	SLP-O-50	SLP-E-46
X5(i) 5-25x56 P	SLP-O-56	SLP-E-46
dS 5-25x52 P	SLP-O-63	SLP-E-46